Knight®
by Midmark

Dental Chair Back Upholstery Installation Instructions

Locate the hardware package. Remove 4 SPRINGS 121005, 4 CUSHION MOUNTING STUDS 121004–2 and 4 SCREWS 151783.

Install the SPRINGS into the bushing on the chair back.

Insert the four SCREWS through the chair back and into the stud, compressing the SPRINGS to permit the SCREWS to be inserted. Tighten the SCREWS 2 to 3 turns into the STUD.

Insert the CHAIR BACK CUSHION over the studs and make sure that the head of the MOUNTING STUD fits through the hole in the plate in the CHAIR BACK CUSHION.

Slide the CHAIR BACK CUSHION down over the studs to lock in place. Make certain that all four STUDS are locked in place. Then tighten the four small screws to achieve the desired tension.

CAUTION: Over tightening of the SCREWS may cause excessive distortion and/or wrinkling of the CHAIR BACK CUSHION.